


Delta Outdoor Assembly Instructions




Ensure that you DO NOT push your knife too far into the box when cutting it open.
Lift the cardboard with one hand while cutting, thereby keeping the blade well away from your furniture.

Opening Box


Assembling your furniture. Please follow steps 1 to 13.




1




2




3




4




5




6




7




8A




8B




9




10



11




12




13


SUN LOUNGE




14




15




16




17




18




19




20



21



22



23

For further assistance, call King Furniture Customer Service on **1300-13-KING**

Delta Outdoor Assembly Instructions




Delta Outdoor Circle Sofa


Ensure that you DO NOT push your knife too far into the box when cutting it open.
Lift the cardboard with one hand while cutting, thereby keeping the blade well away from your furniture.

Opening Box


Assembling your furniture. Please follow steps 1 to 7.




1




2




3




4



5



6




7

Delta Outdoor Assembly Instructions




Delta Outdoor Round Table

Assembling your furniture. Please follow steps 1 to 3.



Delta Outdoor Rectangular Table

Assembling your furniture. Please follow steps 1 to 4.



Delta Outdoor Weather Covers

Please follow steps 1 to 4.

